

Food POS type overview

The Food POS type is mainly used for **carousel**, **shopper** vending machines. These machines are notoriously difficult to track inventory based on a planogram due to their contents and structure.

Gimme introduced a Food POS type that looks and works similarly to a Vending POS type. The main difference is the *cash audit* DEX. Due to the difficulty to match a product position with a DEX ID, parsed DEX files for a Food POS will only contain financial data.